



Assembly instruction GfS e-Bar®

GfS Safety at doors





EMERGENCY EXIT ALARM SECURED



*GfS e-Bar® mechanical has no display

Content

1. Introdu	ction	Seite
1.1.0	0 Safety instructions	4
1.2.	O General functions	5
1.2.	1 Local alarm types	6
1.2.	2 Operation	7
1.3.	0 Mechanical versions of GfS e-Bar®	8
1.3.	1 Mechatronic versions of GfS e-Bar®	9
2. Assem	bly	
2.1.	0 Mounting instructions of GfS e-Bar®	10
2.1.	1 Cut to size with tool kit	11
2.2.	0 Defining the correct length	12
2.3.	0 Adjusting main alarm	13
2.4.	0 Changing the cylinder	14
2.5.	0 Mounting on wooden doors	15
2.5.	1 Mounting on metal doors	16
2.5.	2 Mounting in combination with security escutcheon (4mm)	17
2.6.	0 Battery operation/mains supply — wiring of GfS e-Bar®	18
2.7.	0 Assembly of GfS e-Bar®	19
2.8.	0 Placing the stickers	20
3. Electric	cal connection	
3.1.	0 Terminal board GfS e-Bar® 700 71x	21
3.1.	1 Terminal board GfS e-Bar® 700 73x	22
3.1.	2 Terminal board GfS e-Bar® 700 74x	23
3.2.	0 Wiring diagram GfS e-Bar® 700 71x	24
3.2.	1 Wiring diagram GfS e-Bar® 700 73x	25
3.2.	2 Wiring diagram GfS e-Bar® 700 74x	26
4. GfS e-E	Bar® settings	27
4.1.	O Activate automatic alarm switch-off	27
4.1.	1 Settings of DIP switch	27
4.1.	2 RS485-Interface with MODBUS protocol	27
4.1.	3 Switching color green/red	27
4.1.	4 Changing brightness	27
5. Technic	cal data	28
6. Docum	nentation	
6.1.	0 Service protocol (operator)	29
6.2	Sanga protocol (installar)	30

This document has been produced with the utmost care. GfS does not guarantee the accuracy or completeness of the content of this documentation with respect to texts, pictures , references or information contained therein. The company GfS assumes no liability for damages arising directly, indirectly or accidentally from the use of this documentation. The content of this documentation may be adjusted without notice. It shall not lead to any obligations for GfS in the future.

© Copyright by GfS – Gesellschaft für Sicherheitstechnik GmbH – Hamburg 2012.

This documentation may not be reproduced without written permission of GfS – Gesellschaft für Sicherheitstechnik GmbH in any way, or otherwise used.



1.0 Introduction

1.1.0 Safety instructions

The GfS e-Bar may only be installed acc. to the specifications of the assembly instruction.

- the door must have a smooth running without distortion
- the door leaf should be flat and stiff
- existing door seals must not affect the door function
- the GfS e-Bar® may only be mounted horizontally on doors that open outwards
- the GfS e-Bar® may only be used with approved panic locks and fittings (EN 1125)
- the GfS e-Bar® should be cut to length as required according to the installation instructions
- if used on glass doors, there should be safety glazing
- the GfS e-Bar® is not suitable for use on swing doors



When changing cylinders only use half cylinder with lockable driver! (Type information see technical data)



The assembly must be carried out by qualified staff.

After installation the assembly instruction has to be handed over to the operator.





Protect against water and vandalism!





1.2.0 General functions

Function	GfS e-Bar® mechanic	GfS e-Bar® mechanic with floating contacts	GfS e-Bar® mechatronic 700 73*	GfS e-Bar® mechatronic with emergency exit switch 700 74*
Communicating display accoustic/visual			Х	Х
For door leaf left/right	Х	Х	Х	х
Battery-powered (incl. battery control)			Х	
External power supply			Х	Х
Main alarm with floating contact		Х	Х	Х
Pre-alarm with floating contact		Х	Х	Х
Single release (local or remote)		Х	Х	Х
Permanent release (local or remote)			X	Х
Visual and acoustic "door-too-long-open" alarm			Х	Х
Intrusion alarm			Х	Х
Integrated emergency exit switch				Х
Changing display to green/red			Х	Х
RS 485 MODBUS Interface			Х	х
DIP Switch			Х	Х



1.2.1 Local alarm types



GfS e-Bar® activated

When activated the green LEDs of the wired GfS e-Bar is permanently switched on. The green display means that the door is alarm-secured but might be opened at any time. In case of battery supply, the GfS e-Bar® works in an energy saving mode without background light. The display brightens only for about 15 sec.



Pre-alarm

While slightly pressing the GfS e-Bar® a red flashing light and an accoustic alarm (95 dB A/1m) is emitted, which expires as soon as the GfS e-Bar® is released. The moment the pre-alarm turns into a permanent alarm can be adjusted with a little screw (see p. 13). The pre-alarm can be transmitted to a central display.



Main alarm

When pressing the GfS e-Bar® completely the door is released. At the same time the display flashes an intermittent green light and a permanent alarm sound with 95 dBA. The accoustic and visual alarm can just be switched off by turning the integrated key switch. The main alarm might be transmitted to a central display.

Door-too-long-open-Alarm

Pre-condition for this feature is a Reed contact which is installed on the door and connected to the GfS e-Bar®. When the single release has been activated by the integrated key switch and the door stays open for more than 15 sec. a gentle "Door-too-long-open-Alarm" is emitted in an interval of 3 sec. The alarm sound indicates that an authorized person has left the door open. As soon as the door is closed the sound is off

Battery Control

When battery operated the GfS e-Bar® a gentle warning signal is emitted every 60 sec. as soon as the voltage drops below 7 V. The display is off. The alarm is active till a new battery is connected or the old battery is empty.




1.2.2 Operation



Reset

By briefly turning the key clockwise the main alarm is deactivated. The key needs to be turned by 90° and back. The impulse should be no longer than 1 sec. 15 sec. after this operation the GfS e-Bar® is alarm secured again which is indicated by a green display (mains supply). When battery operated the green display fades away after another 15 sec.. If a reed contact is installed the GfS e-Bar® will be alarm secured the moment the door closes.




Single release

By using the integrated key switch or by employing an external access control system (p. 22, p.23), an authorized person may pass the emergency exit once without causing an alarm.

By briefly turning the key clockwise the single release mode is triggered. The key needs to be turned by 90° and back. The impulse should be no longer than 1 sec. If a reed contact is installed the GfS e-Bar® will be alarm secured the moment the door closes.

If the door is kept open for more than 15 sec. a gentle "Door-too-longopen-Alarm" resounds till the door is closed again.



Permanent release

By using the integrated key switch an authorized person may deactivate the GfS e-Bar® in order to pass the emergency exit for a longer period of time. The permanent release is triggered by turning the key clockwise for at leat 5 sec. The key needs to be turned by 90° and back.

The status is communicated by a raising and lowering brightness of the green display.

The key should be removed. The permanent release is activated till the key is turned again by min. 90° for max. 1 sec. and removed afterwards. Alternatively the permanent release can be set by access control systems, timer etc. (p. 22, p. 23).



1.3.0 Mechanical versions of GfS e-Bar®



1. GfS e-Bar® mechanic

This model is a push bar incl. a picto describing the operation of the GfS e-Bar®. Neither contacts nor electric functions are included. The GfS e-Bar® mechanic will be supplied in three different lengths, which might be shortened individually, in order to adjust the length to the width of the door.


Length in mm	To be shortened by mm	Art. No.
970	180	700 700
1130	160	700 703
1290	160	700 705

2. GfS e-Bar® mechanic with floating contacts

This model is a push bar with floating contacts to generate information on the usage of the push bar.

The items will be delivered with a picto describing the operation of the GfS e-Bar®. The GfS e-Bar® mechanic will be supplied in three different lengths, which might be shortened individually, in order to adjust the length to the width of the door.

Length in mm	To be shortened by mm	Art. No.
970	180	700 710
1130	160	700 713
1290	160	700 715





1.3.1 Mechatronic versions of GfS e-Bar®



1. GfS e-Bar® with integrated alarm (battery operated and/or mains supplied)

This model works either with a 9 V battery which is controlled by the PCB or with mains supply of 10–30 V/DC.

The battery control function checks every 10 hours the voltage. If the voltage drops below 7V, all 60 seconds an accoustic alarm is emitted. The battery has to be changed. When battery operated the GfS e-Bar® works in an energy saving mode which basically means that the green LEDs of the display are permanently switched off.

The intelligent PCB recognizes when an external power supply is connected to the GfS e-Bar[®]. The communicating display shines permanently green. It indicates that the emergency exit is alarm secured. Delivery includes 1 9V battery, 2 keys, 1 picto for display and key switch as well as one sticker explaining the operation on the door.


Length in mm	To be shortened by mm	Art. No.
970	180	700 730
1130	160	700 733
1290	160	700 735
Power supply surface mounted		901 366
Power supply flush mounted		700 006

2. GfS e-Bar® with integrated alarm and emergency exit switch for opening electrically locked doors

The GfS e-Bar with integrated emergency exit switch is operated at 10–30 V/DC which is either supplied by an external power supply or the FWS-02 (Emergency exit control unit). The integrated emergency exit switch with 2 opening contacts might be connected to the emergency exit control unit with a max. load of 3A. Additionally it is recommended to install a reed contact which offers additional features such as immediate activation after the door has been closed and door-too-long-open-alarm.

Delivery includes 1 integrated emergency exit switch, 2 keys, 1 picto for the display and the key switch as well as one sticker explaining the operation on the door.


Length in mm	To be shortened by mm	Art. No.
970	180	700 740
1130	160	700 743
1290	160	700 745
Power supply surface mounted		901 366
Power supply flush mounted		700 006





2.0 Assembly

2.1.0 Mounting instructions of GfS e-Bar®



GfS e-Bar® mechatronic

Remove the screw M3 x 8 (9), unlock the cover hood by turning the key clockwise (2a).

GfS e-Bar® mechanic


While the push bar is pressed 4 remove the cylinder head screw M5 x 8. Tear the cover hood 2 towards the hinge side.

Remove the protective shield (10)

Lift the push bar profile 4 up to its maximum. Hold the lever arm 7 with one hand and remove the push bar profile 4 from the clamping bolt in opposite direction 7a.



2.1.1 Cut to size with tool kit (not included in scope of delivery)



Just mechatronic versions:

Remove carefully the plug of the ribbon cable (5) from the connection circuit board and keep it safe in the base profile. Loosen the slotted grub screws M4x4 (6) and remove them together with the console. Keep the shims (8) as you need them again for the assembly. Clamp the profiles in a vice. The jaws of the vice serve as stop for the shortening tool.

ATTENTION:

The clamping area should be protected by wood/plastic material in order to avoid scratches on the surface of the profile!

Carefully cut the profile with a conventional metal saw along the lug. A straight cut is easier when pressing the blade slightly against the lug. After shortening the profile burr the edges carefully in order to avoid injuries.

ATTENTION:


Do not use "lubricants and coolants" when shortening the mechatronic versions od the GfS e-Bar®. Metal chips must not stay in the GfS e-Bar®. Danger of short-circuit! After shortening insert the console (7) into the base profile. Place the shims (8) (0,8 mm thickness) between the console and the base profile.

IMPORTANT

The shims (8) are designed to avoid pressure marks and deformations by the clamp-connection. Fasten the four cylinder pins M4x4 (6) with a torque between 0.4 Nm and max. 0.5 Nm! Only mechatronic versions: Insert carefully the plug of the ribbon cable (5) into the connection circuit board.




2.2.0 Defining the correct length




Rule of thumb for defining the correct length:

door inside width - 2x backset + 2x lockplate thickness + 30mm = GfS e-Bar® length


Order lengths	Max. shortening length	
970 mm	180 mm	
1130 mm	160 mm	
1290 mm	160 mm	








2.3.0 Adjust pre- and main alarm





2.4.0 Changing the cylinder




Battery holder



Attention:


Use European profile cylinder with lockable cam.


Remove key, put cam on 180°!






2.5.0 Mounting on wooden doors(Metal cover plate 770 013 for wooden doors are not included in shipment)












2.5.1 Mounting on metal doors











2.5.2 Mounting in combination with security escutcheon (4 mm)





2.6.0 Battery operation/mains supply – wiring of GfS e-Bar®





Cable must be fixed with cable tie Connection cable 12-wires with tie GfS Art. No. 770 719

Cable length

DIN left










2.7.0 Assembly of GfS e-Bar®



Lift the lever arms 1 up to its maximum. Hold the lever arm with one hand and pull the push bar profile 2 from the hinge side on the clamping bolt 3 until the push bar profile is engaged. Lift the lever arm with one hand, give some counter pressure on the push bar profile 4 with the other hand in order to avoid that the push bar snaps-out again.


Important: The push bar profile must smoothly but noticably snap-in. Do not force the push bar profile. In case of doubt try again.

Put the protective shield (5) on the support bracket.

Insert the cover hood 7 in the bayonet joint and push it to the end stop. Fix the cover hood with cylinder head screw M5 x 20 8 a) Mechatronic versions 6: turn the key anti-clockwise. A noticable click indicates that the cover hood is locked. b) Mechanic versions: Fix cover hoods with M5x8 cylinder head screws (like lock side).



2.8.0 Placing the stickers






3. Electrical connection

3.1.0 Terminal board GfS e-Bar® 700 71x


Clamp	Signal	Wire colour	Function
1	NO		Relay 1: Pre-alarm
2	NC		Relay 1: Pre-alarm
3	COM		Relay 1: Pre-alarm
4	NO		Relay 2: Main-alarm
5	NC		Relay 2: Main-alarm
6	COM		Relay 2: Main-alarm
17/18			External key switch message out
19/20			External key switch wiring in






3.1.1 Terminal board GfS e-Bar® 700 73x

Clamp	Signal	Color	Function		
1	OV	white	External door reed contact, recommended otherwise jumper (1-2)		
2	GND	black	Mains supply GND		
3	OV	brown	DIP 8 OFF: DIMM at 10% luminiscence (prgrammable see page) DIP 8 ON: Radar triggered pre-alarm		
4	+5V	green	RS485 A Interface (MODBUS)		
5	+5V	yellow	RS485 B Interface (MODBUS)		
6	+ 10 V – 30 V	red	Mains supply 10 V–30 V DC		
7	OV	violett	Electric pulse for single release or permanent signal for permanent opening (2–7) – not avilable when battery operated		
8	NC	grey	Output relay: alarm 30 V/850 mA		
9	COM	blue	Output relay: alarm 30 V/850 mA		
10	NO NO	pink	Output relay: alarm 30 V/850 mA		
11	COM	red/blue	Output relay: pre-alarm 30 V/850 mA. When pre-alarm contact is opened		
12	NO	grey/pink	Output relay: pre-alarm 30 V/850 mA. When pre-alarm contact is closed		
13	COM		Internal emergency exit switch 1 min AWG24		
14	COM		Internal emergency exit switch 2 min AWG24 Cable diameter LIVY 4x 0,25		
15	NO		Internal emergency exit switch 1 min AWG24		
16	NO		Internal emergency exit switch 2 min AWG24		
17	+9 V		+9 V Battery supply		
18	GND	black	GND Battery supply GND		
19	GND		Key Switch (Reset/Programming)		
20	OV		Key Switch (Reset/Programming)		




Switching circuit F4






3.1.2 Terminal board GfS e-Bar® 700 74x






3.2.0 Wiring diagram GfS e-Bar® 700 71x








3.2.1 Wiring diagram GfS e-Bar® 700 73x





3.2.2 Wiring diagram GfS e-Bar® 700 74x





4.0 GfS e-Bar® settings

4.1.0 Activate automatic alarm switch-off

If DIP switch 5 is ON the alarm will automatically switched-off after 3 minutes. If DIP switch 5 is OFF a permanente alarm will resound.

4.1.1 Settings of DIP switch

DIP-Nr.	Function	ON	OFF (factory setting)		
1	Hold open time	+ 6 sec.			
2	Hold open time	+ 12 sec.			
3	Back-light while permanent opening	no backlight	LEDs raising and lowering		
4	Silent alarm	no alarm	alarm		
5	Automatic alarm switch-off	3 min	permanent alarm		
6	Intrusion alarm	activated	deactivated		
7	Alarm delay	15 sec.	deactivated		
8	Special options	Pre-alarm triggered by radar	DIM at 10%		
	Attention: The settings of the DIP switch will just be changed after the GfS e-Bar® has been switched-on again. The DIP switch setting will be overwritten by a MODBUS command.				

4.1.2 RS-485 interface with MODBUS protocol

Up to 127 GfS e-Bar® can be networked. The MODBUS protocol which works with a RS-485 interface offers bi-directional communication. It is thus possibile to monitor and address up to 127 GfS e-Bar® . The communication between different devices is managed by customized masters.

4.1.3 Switching color green/red

When working with mains supply it is up to the operator/dealer to define the color code of the GfS e-Bar[®]. The following steps have to be taken:

- Switch-off the power supply of the GfS e-Bar® and remove the battery. Wait for 10 sec.
- Connect the GfS e-Bar® again
- Turn the key clockwise by 90° and wait for approx. 5 sec till the display indicates that the GfS e-Bar® is deactivated (permanent opening)
- During the following 60 sec press the GfS e-Bar® for about 15 sec.
- The color changes every 2 sec. three times from green to red and back to green
- Release the GfS e-Bar® when the desired color shines and confirm this choice by briefly turning the key clockise by 90°
- Now the chosen color remains active
- The GfS e-Bar® is not in the programming mode anymore but deactivated (permanent opening) .

 In case that the color shall be changed again, you have to restart the process all over again (disconnect the power supply).

4.1.4 Changing brightness

- Switch-off the GfS e-Bar®
- Press entirely the GfS e-Bar®
- Switch-on the GfS e-Bar® again while keeping the GfS e-Bar® pressed for at least 10 sec. untill all LEDs shine
- Release the GfS e-Bar® and oberserve LEDs
- Brightness of LEDs raise and lower for max. 3 times. A too long wait stops the programming mode automatically the desired brightness is achieved confirm the result with the integrated key switch for at least 1 sec.
- Now the value is stored for future operation, the GfS e-Bar leaves the programming mode automatically



Hint: The brightness and darkness need to be confirmed within 1 sec., enough time to operate the key switch.

GfS Safety at doors



5.0 Technical data

Power supply 9 V battery or 12–30 V/DC power supply

Current draw in battery operation mode

Door alarm secured 14 μA

Door open 0,5 mA, briefly 90 mA short-term, intermittent

Pre-alarm 190 mA

Main-alarm in average 160 mA intermittent

Current draw with external power supply

(mains supply or FWS 02)

Door alarm secured 130 mA

Door open 6 mA, briefly 130 mA short-trem intermittent

Pre-alarm 235 mA

Main-alarm in average 190mA intermittent

Battery low signal below 7 V (measured during operation)

Automatic alarm switch off DIP 5 ON: 3 minutes

Turning angle 40° standard 9 mm pin

30° optional 9 mm pin 45° optional 9 mm pin

Power supply 230 V AC/12 - 30 V DC

Reed contact with sabatoge line, incl. 2 m cable,

surface or flush mounted (Art-No. 930 110/930 210)

External connection cable for GfS e-Bar®

GfS e-Bar® 70071x/70073x 12 wires, 12 x 0,14 LIYY (Art. No. 770 719)

GfS e-Bar® 700 74x 20 wires, 20 x 0,25 LIYY

Cable sleeves Metal doors KÜ 480 (Art. No. 901 802)

Cable sleeve with housing, INOX

Cable sleeve 370 mm, Housing 22 x 480 x 17 mm

Wood doors KÜ-R 480 (Art. No. 901 902)

Cable sleeve with housing, INOX

Cable sleeve 370 mm, Housing 22 x 480 x 17 mm

Cylinder 30/10 mm European half cylinder with lockable driver

GfS Safety at doors -



~	^	_							
6.0		111	ጉቦ	Пm	ner	IT 2	H	n	n
U.1	•	$\boldsymbol{\nu}$	JU	uII	ıcı	ııu	u	v	

6.1.0	Service	protocol	(operator)

GfS e-Bar®			
Building			
Manufacturer of lock/lock type			
Panic function D E B E-SV B-SV			
The installation was done properly.			
Lock, lock plate and door hardware form a system acc. to EN 1125 The system has been tested and works properly			
The door can be unlocked with little effort (< 80 N)			
Further comments concerning the building environment:			
After installation the escape route is fully accessible			
The system has been verified and approved			
City, Date	Company (stamp)		
	Signature		

GfS Safety at doors



6.0 6.1.0	Documentation Service protocol (installer)			
GfS e-	Bar®			
Buildi	ng			
Manufacturer of lock/lock type				
Panic function D E B E-SV B-SV				
The in	staller has informed the operator of the following:			
	Function and use			
	Resetting the alarm			
	Special functions			
	Possibility to transmit the alarm to a central display			
	The operator received the installation and operating manual			
	The operator has been informed about the required maintenance activities:			
	- Battery control (at least 1 per month)			
	— System check (at least 1 per year)			
	Visual check (at least 1 per month)			

City, Date	Company (stamp)

Signature

Safety at doors	



